

## Popcorn Machine Instructions

1. Check kettle which is suspended from brackets at the top of the machine. It should be firmly plugged into the receptacle on the underside of the top of the machine. Also, the kettle must mesh with the gear at the top of the machine.
2. Plug popcorn cord into wall receptacle. NOTE: It is important to keep a short electrical distance from the outlet to prevent damage to the equipment. For the best results, this should be no more than 100' and you must use a HEAVY DUTY, 3 PRONG EXTENSION CORD AND PLUG INTO A SEPARATE, DEDICATED 110/120 VOLT, 20 AMP ELECTRICAL CIRCUIT.
3. Turn kettle heat switch to the "ON" position, turn kettle motor switch to "ON" position. You must never operate the kettle without BOTH switches on.
4. Allow 5-10 minutes for the kettle to fully warm up. Pour contents of oil package into kettle and place 3 to 4 kernels of corn into kettle.
5. When the popcorn starts popping, add the remaining kernels. When the popping of that package is complete, empty the kettle into the machine, return the kettle to the gear and empty the next package into the kettle. It is not necessary to wait 5-10 minutes as the kettle is already heated. You may add both the oil and the popcorn at the same time.
6. **Any time you cut the motor switch OFF, you MUST cut the heat switch OFF.**